## **SIEMENS**

Data sheet 3RS2500-2AA30



Temperature monitoring relay Pt100, thermocouple J, K 1 threshold value, width 22.5 mm Overshoot and undershoot 24 V AC/DC 1 change-over contact, quiescent current principle Spring-type terminal (push-in)

Figure similar

product brand name	SIRIUS
product designation	Temperature monitoring relay
design of the product	Analog multifunction device, 1 sensor, 1 threshold value
product type designation	3RS2
General technical data	
product function	temperature monitoring
display version LED	Yes
insulation voltage for overvoltage category III according to IEC 60664 with degree of pollution 3 rated value	300 V
test voltage for isolation test	4 kV
degree of pollution	3
protection class IP	20
shock resistance acc. to IEC 60068-2-27	11g / 15 ms
vibration resistance acc. to IEC 60068-2-6	10 55 Hz: 0.35 mm
mechanical service life (switching cycles) typical	10 000 000
electrical endurance (switching cycles) at AC-15 at 230 V typical	100 000
thermal current of the switching element with contacts maximum	5 A
certificate of suitability relating to ATEX	no
reference code acc. to IEC 81346-2	K
measurable temperature	
• initial value	-50 °C
• full-scale value	1 000 °C
Substance Prohibitance (Date)	01.05.2012 00:00:00
product function	
<ul> <li>error memory</li> </ul>	No
external reset	No
design of the sensor connectable	Resistance sensors: Pt100 Thermocouples: Type J, K
Control circuit/ Control	
type of voltage of the control supply voltage	AC/DC
control supply voltage at AC	
at 50 Hz rated value	24 24 V
• at 60 Hz rated value	24 24 V
control supply voltage 1 at AC	
• at 50 Hz rated value	24 V
● at 50 Hz	24 24 V
<ul> <li>at 60 Hz rated value</li> </ul>	24 V
• at 60 Hz	24 24 V

control supply voltage 2 at AC	
at 50 Hz rated value	24 V
at 60 Hz rated value	24 V
control supply voltage at DC rated value	24 24 V
control supply voltage 1	
<ul> <li>at DC rated value</li> </ul>	24 V
• at DC	24 24 V
operating range factor control supply voltage rated	
value at DC	
• initial value	0.85
• full-scale value	1.1
operating range factor control supply voltage rated value at AC at 50 Hz	
initial value	0.85
full-scale value	1.1
operating range factor control supply voltage rated value at AC at 60 Hz	
• initial value	0.85
• full-scale value	1.1
supply voltage frequency for auxiliary and control circuit	50 60 Hz
number of measuring circuits	1
buffering time in the event of power failure minimum	20 ms
Precision	
relative metering precision	5 %
Short-circuit protection	
of the fuse link     for short-circuit protection of the NO contacts of the	gL/gG: 6 A or MCB type C: 1 A
relay outputs required  • for short circuit protection of the NC contacts of the	gL/gG: 6 A or MCB type C: 1 A
relay outputs required	
design of the fuse link	// O O A . MOD / O / A
<ul> <li>for short-circuit protection of the NO contacts of the relay outputs safety-related required</li> </ul>	gL/gG: 2 A or MCB type C: 1 A
<ul> <li>for short circuit protection of the NC contacts of the relay outputs safety-related required</li> </ul>	gL/gG: 2 A or MCB type C: 1 A
Communication/ Protocol	
protocol is supported IO-Link protocol	No
Auxiliary circuit	
material of switching contacts	AgSnO2
number of NC contacts for auxiliary contacts	0
number of NO contacts for auxiliary contacts	0
number of CO contacts for auxiliary contacts	1
operational current of auxiliary contacts at DC-13	
• at 24 V	1 A
• at 125 V	0.2 A
• at 250 V	0.1 A
contact reliability of auxiliary contacts	one incorrect switching operation of 100 million switching operations (17 V, 5 mA)
contact rating of auxiliary contacts according to UL	R300 / B300
influence of the surrounding temperature	0.05% per K deviation from T20
operating frequency rated value	50 60 Hz
	3 A
ampacity of the output relay at AC-15 at 250 V at 50/60 Hz	3.7
ampacity of the output relay at DC-13	1.0
• at 24 V	1 A
• at 125 V	0.2 A
continuous current of the DIAZED fuse link of the output relay	6 A
continuous current of DIAZED fuse link of the output relay safety-related	2 A
Electromagnetic compatibility	
EMC emitted interference acc. to IEC 60947-1	Class B
conducted interference	

<ul><li>due to burst acc. to IEC 61000-4-4</li></ul>	2 kV (power ports), 1 kV (signal ports)
<ul> <li>due to conductor-earth surge acc. to IEC 61000-4-5</li> </ul>	2 kV (line to ground)
<ul> <li>due to conductor-conductor surge acc. to IEC</li> </ul>	1 kV (line to line)
61000-4-5	
field-based interference acc. to IEC 61000-4-3	10 V/m
electrostatic discharge acc. to IEC 61000-4-2	6 kV contact discharge / 8 kV air discharge
Galvanic isolation	
design of the electrical isolation	galvanic isolation
galvanic isolation	V
between input and output	Yes
between the voltage supply and other circuits	No
Connections/ Terminals	V.
product component removable terminal for auxiliary and control circuit	Yes
type of electrical connection	Push-in terminal
for auxiliary and control circuit	spring-loaded terminals (push-in)
type of connectable conductor cross-sections	
• solid	0.5 4 mm²
<ul> <li>finely stranded with core end processing</li> </ul>	0.5 2.5 mm²
<ul> <li>finely stranded without core end processing</li> </ul>	0.5 4 mm²
at AWG cables solid	20 12
at AWG cables stranded	20 12
connectable conductor cross-section	
• solid	0.5 4 mm²
<ul> <li>finely stranded with core end processing</li> </ul>	0.5 2.5 mm <sup>2</sup>
finely stranded without core end processing	0.5 4 mm²
AWG number as coded connectable conductor cross section	
• solid	20 12
• stranded	20 12
Installation/ mounting/ dimensions	
mounting position	any
mounting position fastening method	any screw and snap-on mounting onto 35 mm standard mounting rail
fastening method height	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm
fastening method height width	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm
fastening method height width depth	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm
fastening method height width depth required spacing	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm
fastening method height width depth required spacing • with side-by-side mounting	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — backwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards — at the side	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — at the side - to grounded parts — forwards — backwards — backwards — backwards — upwards — at the side — downwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards — at the side	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — backwards — the side — downwards — at the side — downwards — at the side — downwards • for live parts — forwards — backwards — backwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — backwards — backwards — in the side — downwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — horwards — backwards — upwards	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm 0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — backwards — upwards — at the side — downwards — at the side — downwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — downwards — downwards — at the side — downwards — at the side	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for live parts — forwards — backwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards — backwards — backwards — backwards — backwards — at the side Ambient conditions	screw and snap-on mounting onto 35 mm standard mounting rail  100 mm  22.5 mm  90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 m
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — the side Ambient conditions installation altitude at height above sea level maximum	screw and snap-on mounting onto 35 mm standard mounting rail 100 mm 22.5 mm 90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 mm
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — the side — downwards — at the side  Ambient conditions installation altitude at height above sea level maximum ambient temperature	screw and snap-on mounting onto 35 mm standard mounting rail  100 mm  22.5 mm  90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 m
fastening method height width depth required spacing  • with side-by-side mounting — forwards — backwards — upwards — downwards — at the side • for grounded parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — at the side — downwards • for live parts — forwards — backwards — upwards — backwards — upwards — the side Ambient conditions installation altitude at height above sea level maximum	screw and snap-on mounting onto 35 mm standard mounting rail  100 mm  22.5 mm  90 mm  0 mm 0 mm 0 mm 0 mm 0 mm 0 m

-40 ... +85 °C • during transport 70 %

relative humidity during operation

Certificates/ approvals

**General Product Approval** 

**EMC** 

**Declaration of** Conformity













**Declaration of** Conformity

Marine / Shipping

other

**Miscellaneous** 



Confirmation

## **Further information**

Information- and Downloadcenter (Catalogs, Brochures,...)

https://www.siemens.com/ic10

Industry Mall (Online ordering system)

https://mall.industry.siemens.com/mall/en/en/Catalog/product?mlfb=3RS2500-2AA30

Cax online generator

http://support.automation.siemens.com/WW/CAXorder/default.aspx?lang=en&mlfb=3RS2500-2AA30

Service&Support (Manuals, Certificates, Characteristics, FAQs,...)


https://support.industry.siemens.com/cs/ww/en/ps/3RS2500-2AA30


Image database (product images, 2D dimension drawings, 3D models, device circuit diagrams, EPLAN macros, ...)

http://www.automation.siemens.com/bilddb/cax\_de.aspx?mlfb=3RS2500-2AA30&lang=en

**Characteristic: Derating** 

https://support.industry.siemens.com/cs/ww/en/ps/3RS2500-2AA30/manual





last modified:

5/1/2021